



- ◆ Slide-out fuse-box with 2 off 5x20 fuses - (1 + 1 spare, max 10A ).
- ◆ To be used ONLY for resistive loads (water-heater, electric space-heater, etc...) 10A max.
- ◆ The fused spur must be connected only by qualified technicians.




**CBE S.r.l.**

Via Vienna, 4 - z.i. Spini (settore D)  
38121 Trento - Italy  
Tel. +39 0461 991598 - Fax +39 0461 960009  
www.cbe.it - E-mail: cbe@cbe.it



## FUSED SPUR



3 - 5 - 10 A

Rev. 02

- ◆ Slide-out fuse-box with 2 off 5x20 fuses - (1 + 1 spare, max 10A ).
- ◆ To be used ONLY for resistive loads (water-heater, electric space-heater, etc...) 10A max.
- ◆ The fused spur must be connected only by qualified technicians.




**CBE S.r.l.**

Via Vienna, 4 - z.i. Spini (settore D)  
38121 Trento - Italy  
Tel. +39 0461 991598 - Fax +39 0461 960009  
www.cbe.it - E-mail: cbe@cbe.it



## FUSED SPUR



3 - 5 - 10 A

Rev. 02

- ◆ Slide-out fuse-box with 2 off 5x20 fuses - (1 + 1 spare, max 10A ).
- ◆ To be used ONLY for resistive loads (water-heater, electric space-heater, etc...) 10A max.
- ◆ The fused spur must be connected only by qualified technicians.




**CBE S.r.l.**

Via Vienna, 4 - z.i. Spini (settore D)  
38121 Trento - Italy  
Tel. +39 0461 991598 - Fax +39 0461 960009  
www.cbe.it - E-mail: cbe@cbe.it



## FUSED SPUR



3 - 5 - 10 A

Rev. 02

- ◆ Slide-out fuse-box with 2 off 5x20 fuses - (1 + 1 spare, max 10A ).
- ◆ To be used ONLY for resistive loads (water-heater, electric space-heater, etc...) 10A max.
- ◆ The fused spur must be connected only by qualified technicians.




**CBE S.r.l.**

Via Vienna, 4 - z.i. Spini (settore D)  
38121 Trento - Italy  
Tel. +39 0461 991598 - Fax +39 0461 960009  
www.cbe.it - E-mail: cbe@cbe.it



## FUSED SPUR



3 - 5 - 10 A

Rev. 02